



Drop-Down Door Microwave and Speed Oven Pro Handle Installation

www.wolfappliance.com

CONTENTS

1	Handle
2	Standoff
2	Screw, #10-24 x $\frac{1}{2}$ "

INSTALLATION

- 1 Use a 2.5mm Allen wrench to loosen the set screws on the inside of each existing handle standoff, then remove the handle.
- 2 Place standoffs on new handle and secure the standoffs to the handle using the #10-24 x $\frac{1}{2}$ " screws provided.
- 3 Verify the logos on the outside of the standoffs are positioned properly.
- 4 Place the new handle on the door and secure the existing set screws. Do not over tighten.

