HTS60

BRAVIA Theater System 6, 5.1ch with subwoofer, Dolby Atmos[®]/DTS:X[®] compatible

Turn up the energy with BRAVIA Theater System 6 all-in-one 5.1ch system. Featuring 10 total speakers, including a subwoofer and rear speakers, and with support for Dolby Atmos[®] and DTS:X[®], movies will explode with powerful, immersive surround sound. Ready to entertain? Energize your next party with room-filling multi-stereo sound.



Bullets

- · Hear cinematic surround sound and deep bass with 3 front-firing speakers, two rear speakers, and included subwoofer.
- Get the best streaming experience with support for Dolby Atmos[®] and DTS:X[®].
- Catch every word in the scene with dedicated center channel speaker.
- Multi Stereo enhances your listening experience by playing the same sound from all speakers, creating a room-filling sound boost
- Pair with compatible BRAVIA TVs to control the soundbar from the TV menu and take advantage of Voice Zoom 3[™] for enhanced dialogue.²
- Use BRAVIA Connect app to easily control BRAVIA Theater from your smartphone and change volume and other settings.⁸
- Enjoy wireless music streaming from your smartphone with Bluetooth® technology. 3,4
- Your music is up-mixed, restoring acoustic details for a richer listening experience.

Features

Cinema is coming home

Feel the emotion and excitement of the movies with BRAVIA Theater. Our decades of professional filmmaking experience allow us to faithfully recreate the creator's vision at home with intricate surround sound and spatial audio. Immerse yourself in the story through powerful sound that fills every corner of the room, in lifelike accuracy.

Cinematic 5.1ch surround sound

Acoustically designed for cinematic surround sound with 3 front-firing speakers, including a dedicated center speaker for clear dialogue, and two rear speakers that deliver immersive audio all around you. The included subwoofer provides rich, powerful room-filling bass.

Sound straight from cinema

Get the best streaming experience and authentic cinema sound as the creator's intended with support for industry-standard formats Dolby Atmos® and DTS:X®.1

Center speaker for clear dialogue

A dedicated center channel speaker ensures clear voice reproduction in every scene. From intense conversations to hushed whispers, you'll catch every word, enhancing your experience across all types of content.

Room filling sound with Multi Stereo

Multi Stereo enhances your listening experience by playing the same sound from all speakers, creating a room-filling sound boost.

BRAVIA Theater and BRAVIA TV, the perfect pair

Pair BRAVIA Theater with a compatible BRAVIA TV for an unmatched audio-visual experience. Control soundbar settings on the TV's Quick Settings menu and adjust volume and sound settings with a single remote. When paired with select BRAVIA TVs, take advantage of Voice Zoom 3[™], which uses AI to improve dialogue and ensure people's voices are always loud and clear.²

Do it all with BRAVIA Connect app

Easily control BRAVIA Theater from your smartphone. The BRAVIA Connect app guides you through initial setup and lets you adjust volume, sound field and more.⁸

Wireless Bluetooth® streaming

Enjoy wireless music streaming from your smartphone and other devices with Bluetooth® technology. 3,4

Give your favorite music a boost

Enjoy tracks like you're in the recording studio with the artist. Digital Sound Enhancement Engine (DSEE) up-mixes compressed digital music, restoring acoustic details for a richer listening experience.

Specification

Amplifier Type Digital Amplifier Amplifier Channels 5.1 ch Application Sony Bravia Connect Yes Audio Formats High Resolution Audio Yes Dolby Digital Dolby Digital Plus Dolby TrueHD, Dolby Atmos. DTS, DTS HD High Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS: X, LPCM: 2ch / 5.1 ch / 7.1 ch Optical Input Dolby Digital Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch / 5.1 ch / 7.1 ch Optical Input Dolby Digital Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch Bluetooth® Communication (Receiver) AAC, SBC Details Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Subwoofer: 0.5 W, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode) Terminals Power Consumption (Network Standby Mode / Low Power Mode) Terminals Power Consumption (Network Standby Mode / Low Power Mode) Terminals Power Consumption (Network Standby Mode / Low Power Mode) Terminals Power Consumption (Network Standby Mode / Low Power Mode) Power Consumption (Network Standby Mode / Low Power Moder: After 20 minutes, Wireless Amp: not available Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function, Wireless Amp: not available (Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Moder: After 20 minutes (Wireless Audio) Subwoofer: After 20 minu	Amplifier	
Application Sony Bravia Connect Yes Audio Formats High Resolution Audio Yes Dolby Digital, Dolby Digital Plus, Dolby TrueHD, Dolby Atmos, DTS, DTS HD High Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS: X, LPCM: 2ch / 5.1ch / 7.1ch Optical Input Dolby Digital, Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch Studentosth® Communication (Receiver) AAC, SBC Details Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Standby Mode / Low Power Mode) Subwoofer: not available, Wireless Amp: not available Off Mode / Standby Mode / Low Power Mode / Cow Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Audio, all terminals and networks connected) Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Networked Standby Mode Activated Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available Wireless Network(s) On/Off Switch Subwoofer: Press (Muting) , (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) Yes	Amplifier Type	Digital Amplifier
Sony Bravia Connect Yes	Amplifier Channels	5.1 ch
Audio Formats High Resolution Audio Yes Dolby Digital, Dolby Digital Plus, Dolby TrueHD, Dolby Atmos, DTS, DTS HD High Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS; X, LPCM: 2ch / 5.1ch / 7.1ch Optical Input Dolby Digital, Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch Bluetooth® Communication (Receiver) AAC, SBC Details Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Subwoofer: not available, Wireless Amp: not available Off Mode / Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode) Subwoofer: 0.5 W, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected) Networked Standby Mode Activated — Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio, all terminals and networks connected) Wireless Network(s) On/Off Switch Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) EARC Yes Bravia SYNC Yes	Application	
High Resolution Audio Yes Dolby Digital, Dolby Digital Plus, Dolby TrueHD, Dolby Atmos, DTS, DTS HD High Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS: X, LPCM: 2ch / 5.1ch / 7.1ch Optical Input Dolby Digital, Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch Bluetooth® Communication (Receiver) AAC, SBC Details Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode) - Terminals Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected) Networked Standby Mode Activated Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: After 20 minutes (Wireless Audio, all terminals and networks connected) Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: After 20 minutes (Wireless Audio) Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) EARC Yes Bravia SYNC	Sony Bravia Connect	Yes
Dolby Digital, Dolby Digital Plus, Dolby TrueHD, Dolby Atmos, DTS, DTS HD High Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS: X, LPCM: 2ch / 5.1ch / 7.1ch Optical Input Dolby Digital, Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch Bluetooth® Communication (Receiver) AAC, SBC Details Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Subwoofer: 0.5 W, Wireless Amp: not available Off Mode / Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks available, Wireless Amp: not available Cechneted), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Subwoofer: After 20 minutes (HDMI CEC), Bluetooth® function, Wireless Amp: not available, Amp: After 20 minutes (Wireless Audio) Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) Yes Bravia SYNC Yes	Audio Formats	
Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS: X, LPCM: 2ch / 5.1ch / 7.1ch	High Resolution Audio	Yes
Bluetooth® Communication (Receiver) Details Subwoofer 60 W / Wireless Amp 30 W Power Consumption 'Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode) Power Consumption (Network Standby Mode) Networked Standby Mode Activated — Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected) Networked Standby Mode Activated — Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Subwoofer: Perss (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes	HDMI EARC	Resolution Audio, DTS HD Master Audio, DTS ES, DTS 96 / 24, DTS: X, LPCM: 2ch /
Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Subwoofer: 0.5 W, Wireless Amp: not available Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode) Activated Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Amp: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Wireless Network(s) On/Off Switch Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) EARC Yes Bravia SYNC Yes	Optical Input	Dolby Digital, Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, LPCM 2ch
Subwoofer 60 W / Wireless Amp 30 W Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode) Power Consumption (Network Standby Mode / Low Power Mode) Subwoofer: After 20 minutes, Wireless Amp: not available Networked Standby Mode Activated – Subwoofer: After 20 minutes (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) = Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) EARC Yes Pravia SYNC Yes	Bluetooth® Communication (Receiver)	AAC,SBC
Power Consumption *Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Subwoofer: 0.5 W, Wireless Amp: not available Subwoofer: After 20 minutes, Wireless Amp: not available Power Consumption (Network Standby Mode / Low Power Mode Activated) Power Consumption (Network Standby Mode Activated - Terminals Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Networked Standby Mode Activated - Terminals Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Wireless Network(s) On/Off Switch Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) Yes Bravia SYNC Yes	Details	
"Approx Wall-Mountable Yes Eco and Energy Saving Power Consumption (Off Mode) Subwoofer: not available, Wireless Amp: 0.3 W Power Consumption (Standby Mode / Low Power Mode) Subwoofer: 0.5 W, Wireless Amp: not available Off Mode / Standby Mode / Low Power Mode of Mode / Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Networked Standby Mode Activated - Terminals Networked Standby Mode Activated - Terminals Wireless Network(s) On/Off Switch Wireless Network(s) On/Off Switch Wireless Network(s) On/Off Switch Number of Input/Output Input / Output: -/ 1 (eARC / ARC) EARC Yes Power Consumption (Network Standby Mode / Low Power Mode / Subwoofer: After 20 minutes, Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: -/ 1 (eARC / ARC) EARC Yes		Subwoofer 60 W / Wireless Amp 30 W
Eco and Energy Saving	Power Consumption	
Power Consumption (Off Mode) Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode) Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes		
Power Consumption (Off Mode) Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode / Subwoofer: 0.5 W, Wireless Amp: not available Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode) - Terminals Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Networked Standby Mode Activated - Terminals Networked Standby Mode Activated - Terminals Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes		Yes
Power Consumption (Standby Mode / Low Power Mode) Off Mode / Standby Mode / Low Power Mode Subwoofer: 0.5 W, Wireless Amp: not available Power Consumption (Network Standby Mode) – Terminals Networked Standby Mode Activated – Terminals Networked Standby Mode Activated – Terminals Wireless Network(s) On/Off Switch Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function, Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: not available, Subwoofer: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Subwoofer: Press (Mutting) , (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes	Eco and Energy Saving	
Low Power Mode) Off Mode / Standby Mode / Low Power Mode Activated Power Consumption (Network Standby Mode) – Terminals Networked Standby Mode Activated – Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (Wireless Audio) Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes	Power Consumption (Off Mode)	Subwoofer: not available, Wireless Amp: 0.3 W
Mode Activated Power Consumption (Network Standby Mode) – Terminals Subwoofer: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® function, all terminals and networks connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Networked Standby Mode Activated – Terminals Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Subwoofer: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function., Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes		Subwoofer: 0.5 W, Wireless Amp: not available
Mode) – Terminals Connected) , Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks connected) Networked Standby Mode Activated – Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function), Wireless Amp: not available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Subwoofer: Press (Muting) , (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes		Subwoofer: After 20 minutes, Wireless Amp: not available
Available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless Amp: After 20 minutes (Wireless Audio) Wireless Network(s) On/Off Switch Subwoofer: Press (Muting) , (Volume) -, and (Volume) + in that order within 5 seconds on the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) Yes Bravia SYNC Yes		connected), Wireless Amp: 0.5 W (Wireless Audio, all terminals and networks
Wireless Network(s) On/Off Switch the supplied remote control to turn on / off the Bluetooth® function. , Wireless Amp: not available HDMI Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes		available, Subwoofer: After 20 minutes (HDMI CEC, Bluetooth® function) / Wireless
Number of Input/Output Input / Output: - / 1 (eARC / ARC) EARC Yes Bravia SYNC Yes	Wireless Network(s) On/Off Switch	11
EARC Yes Bravia SYNC Yes	HDMI	
Bravia SYNC Yes	Number of Input/Output	Input / Output: - / 1 (eARC / ARC)
	EARC	Yes
HDMI CEC Yes	Bravia SYNC	Yes
	HDMI CEC	Yes
Interface	Interface	
Input And Output Terminals Optical audio input, Optical audio input, Analogue audio input (stereo mini), USB typeA: Yes (only for update)	Input And Output Terminals	
Bluetooth® version: 5.3		Bluetooth® version: 5.3

trademarks and trade namesare those of their respective owners.
SBC,AAC
907 x 64 x 90 mm
35 3/4 in x 2 5/8 in x 3 5/8 inch
2.6 kg
5 lb 12 oz
275 x 388 x 388 mm
11.6 kg
106 x 216 x 98 mm
4 1/4 in x 8 5/8 in x 3 7/8 inch
0.89 kg
1 lb 16 oz
175 x 52 x 175 mm
7 in x 2 1/8 in x 7 inch
0.76 kg
1 lb 11 oz
Sound Field (Upmix / Multi Stereo)
Night Mode, Voice Mode
S-Force PRO, Vertical Surround Engine, DTS Virtual: X
DSEE
5.1 ch (10 Speaker Units)
SS-S60
SA-WS60
SS-SS60
Wired
AC Cord, Batteries for remote commander, Foot, HDMI Cable, Plug Adaptor, Quick Setup Guide, Reference Guide, Remote Control, Wall mounting template, Warranty Card

^{1.} Dolby Atmos and DTS:X content compatible with streaming services or compatible content device connected via HDMI input (sold separately).

- 2. Voice Zoom 3 works with compatible BRAVIA TVs. For full compatibility list: https://www.sony.net/hav_faq.
- 3. Interoperability and compatibility among Bluetooth® devices vary.
- 4. The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.

 5. Compatible with select BRAVIA TVs. For full compatibility list: https://www.sonv.net/hav-faq.

 6. Compatible with TV models: BRAVIA 5, BRAVIA 9, BRAVIA 9, BRAVIA 8 II.

- Applicable TV models when the TV stand is set to inside position: BRAVIA 9 (85"/75"/65"), BRAVIA 8 (77"/65"/55"), BRAVIA 7 (85"/75"/65"/55"), BRAVIA 5 (85"/75"/65"/55").
- 8. BRAVIA Connect app must be installed on a smartphone. The smartphone and the product must be connected to the same home network. Download app at Google Play and the App Store. Network services, content, and operating system and software subject to terms and conditions and may be changed, interrupted or discontinued at any time and may require fees, registration, and credit card information. Feature availability of the integrated remote with TVs and home theater products may vary depending on home theater product.

© 2025 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited.
Sony, BRAVIA, BRAVIA Theater and the Sony logo are trademarks of Sony Corporation. All other trademarks are trademarks of their respective owners. Features and specifications are subject to change without notice. Screen images simulated.