



Whirlpool Model: WFGS3030RW

30-inch Gas Range with Crispy Mode and Dishwasher Safe Grates

Color White

Product Description

Dial up the crunch for an effortlessly easy crispy finish with Crispy Mode on this Whirlpool 30-inch Gas Range. Take preheating off your plate and cook up frozen faves with No Preheat Mode, and use the SpeedHeat™ Burner to boil 20% faster* with high heat. Enjoy quick and easy cleanup with Dishwasher-Safe Cast Iron Grates.
*Compared to 9.5K burner on the same model.

Specifications

Certifications

ADA Compliant	No
UL	Yes
Prop 65	

Oven Cavity Details

Number of Oven Racks	2
Oven Rack Type	Standard
Broiler Location	Top Center
Oven Cleaning Type	Steam Clean
Door Removable	Yes
Number of Oven Lights	1
Oven Light Type	Incandescent
Interior Color	Grey
Number of Rack Guides	5
Hidden Bake Element	Yes
Oven Cooking System	Thermal
Broiler Element Power	1,900 W
Bake Element Power	16,500 BTU
Automatic Convection	No
Oven Light Switch Location	Oven Control

Details

Cooktop Configuration	All Burners
Fuel Type	Gas
LP Convertible	Yes - Kit Included
Natural Gas Convertible	Yes
Power Outage Compatible	Yes
Range Type	Freestanding
Air Fry	No
Oven Selections	Audible Signal Bake Broil Cancel/Off Clock Control Lock Cook Time Indicator Crispy Mode Delay Start Frozen Bake Keep Warm/Warm Hold Timer

Element/Burner Details

Cooktop Element Style	Sealed Burners
Left Front Element-Burner	15,000 BTU
Left Front Element-Burner	SpeedHeat™
Left Rear Element-Burner	9,500 BTU
Left Rear Element-Burner	Standard
Number of Cooking Element-	4
Right Front Element-Burner	15,000 BTU
Right Front Element-Burner	SpeedHeat™
Right Rear Element-Burner	5,000 BTU
Right Rear Element-Burner	Simmer
Number of Grates	2

Exterior Details

Door Type	Glass
Handle Material	Metal
Handle Color	White
Handle Type	Reach Through Handle
Knob Color	White
Knob Type	Plastic
Oven Control Location	Backguard
Oven Control Type	Electronic Touch
Oven Window Size	Extra Large

Grate Details

Grate Details	Continuous Dishwasher Safe Matte Finish Porcelain Coated Cast
---------------	--

Dimensions

Cutout Depth	24
Cutout Height	36
Cutout Width	30.125
Depth	27.2
Depth Closed Excluding	22.9
Depth Closed Including	25.16
Depth With Door Open 90	45.39
Gross Weight	162.81
Height	46.25
Net Weight	151.13
Oven Interior Height	18.375
Oven Interior Depth	19
Oven Interior Width	25
Width	29.875
Capacity	5.1
Common Size	30.0
Maximum Height	47.0781
Minimum Height	36
Console Language	English Spanish

Smart Compatibility

Connectivity	No
--------------	----

Controls

Display Color	Blue
---------------	------

Cooktop Details

Auto Re-ignition	No
Cooktop Control Knob Color	White
Cooktop Control Location	Front
Cooktop Control Knob Type	Plastic
Cooktop Control Type	Knobs
Cooktop Surface Color	Black
Cooktop Surface Material	Porcelain Coated Steel
Griddle Included	Optional Accessory
Heating Element On	No
Hot Surface Indicator Light	No
Ignition Type	Electronic

Key Features

Crispy Mode
No Preheat Mode
2 SpeedHeat™ Burners
Dishwasher-Safe Cast Iron Grates
Steam Clean
Broil
Keep Warm Setting
Large Oven Capacity
Control Lock Mode
Hidden Bake Element
Delay Start
Large Oven Window
Porcelain Enamel Cooktop

Electrical Requirements

Power Cord Included	Yes
Amps	15
Hz	60
Volts	120

UPC Listing

Model : WFGS3030RB	UPC : 883049955681
Model : WFGS3030RS	UPC : 883049955674
Model : WFGS3030RW	UPC : 883049955698
Model : WFGS3130TS	UPC : 883049961873