# TOP LOAD DIGITAL DIAL CYCLE & FABRIC CARE GUIDE

Go from start to finish with one quick turn or choose from more than 25 wash and dry cycles for total laundry control.



Get a fast start by choosing one of the pre-loaded wash and dry cycles.

	WASH CYCLES	CYCLE DESCRIPTION	DRY CYCLES	CYCLE DESCRIPTION		
	Normal	Mixed loads and cotton or linen fabrics	Normal	Mixed loads and cotton or linen fabrics		
	Al Wash	Optimizes cycle based on contents of laundry	Al Dry	Optimizes cycle based on fabrics		
	Bedding	Bulky items, pillows, blankets or comforters	Bedding	Bulky items, pillows, blankets or comforters		
	Delicates	Lingerie, sheer or easily damaged fabrics	Delicates	Lingerie, sheer or easily damaged fabrics		
	Towels	Includes high-speed spin to remove excess water	Towels Dry	Designed for towels		
CYCLES	Quick Wash			Small loads		
	Heavy Duty	Heavily soiled laundry, especially cotton fabrics	Timed Dry	Lets you manually select the drying time		
LOADED	Deep Wash	Adds additional water for heavily soiled items	Antibacterial	A high-temperature dry cycle		
PRE	Waterproof	Water-resistant clothing or mattress covers	Perm. Press	Minimizes wrinkles in "wrinkle-free" fabrics		
ī	Prewash+Normal	Prewash lightly stained clothing	SteamFresh®	Reduces wrinkles and odors using steam		
	Rinse+Spin	Rinses and spins items only	Heavy Duty	Extra drying for heavier fabrics		
	Spin Only	Drains and spins with no wash or rinse	Air Dry	Tumble dries heat-sensitive items		
	Perm. Press	Minimizes wrinkles in "wrinkle-free" fabrics				
	Tub Clean	Designed to clean the inside of the washer	••••			


Or, quickly and easily customize your laundry with special cycles for a wide range of load types.

	WASH CYCLES	CYCLE DESCRIPTION		DRY CYCLES	CYCLE DESCRIPTION
OTHER AVAILABLE CYCLES	Baby Bibs	Soaks and cleans food-stained baby items	OTHER AVAILABLE CYCLES ——————	Super Dry	Thoroughly dries cotton fabrics
	Baby Wear	Designed for lightly soiled baby clothing		Jeans	Designed specifically for jeans
	Bright Whites™	Use with white fabrics only		Blanket Refresh	▶ Warms and fluffs up blankets
	Dresses	Lightly soiled, delicate dresses		Low Temp Dry	Reduces energy consumption
	Econowash	Helps reduce normal cycle energy consumption		Overnight Dry	Energy efficient cycle dries a small load overnight
	Juice/Food Stains	Powerful wash for heavily soiled items		Easy Ironing	Leaves clothes slightly damp for easy ironing
	Kids Wear	High temperatures for heavily soiled items		Small Load	Small or light items
	Overnight Wash	Helps reduce spin noise and wrinkling		Large Load Dry	Dryer is approximately half full
		Quickly washes a single item		X Large Load Dry	Dryer is very full
	Sweat Stains	Helps remove sweat stains and odors		SteamSanitary®	Reduces odors using steam and high temperature
	Swimwear	Gently removes chlorine or salt from swimwear		Rack Dry	Dries items that should not be tumbled (install the rack)
	Small Load	A small number of normally soiled items		Wrinkle Prevention	Prevents wrinkles by tumbling clothes after the cycle
	Large Load	Washer is approximately half full	•		
	X Large Load	Washer is very full			

Intuitive dial control gives you more of what you need with each turn, from descriptions of each setting and helpful prompts to status updates and remaining cycle time.

### GET LAUNDRY DAY DIALED IN—IT'S EASY

Load, set and go—laundry day is just that easy with LG's LCD dial and touch panel, and you can even customize the interface to display English, Spanish or French.



## **COMPLETELY CUSTOMIZE YOUR CYCLE**

Modify any cycle by using the touch panel to change settings like temperature, spin speed and soil level to your liking. You can delay the start of a load and even add options like Deep Fill.

#### **MODIFY ANY CYCLE**

Press pads such as Temp., Spin or Soil to make adjustments to the selected cycle before you hit Start.

#### ADD OTHER OPTIONS

Options for each cycle will light up on the touch panel—press the one you want and then make selections on the dial.

#### **GO BACK OR SELECT**

Press the check mark on the dial to confirm your choice or hit the back button to see the previous screen.