PBX-1520

QFX

WHERE THE PARTY BEGINS®

INSTRUCTION MANUAL

PBX-1520说明书2025.3.6　　尺寸：宽127mmX高190mm

PBX-1520 SAFETY / SEGURIDAD / SÉCURITÉ

SAFETY

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN.
To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers. Clean only with a dry cloth. Users should exhibit extra safety and follow all precautions as they are stated.

LA SEGURIDAD

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO QUITE LA CUBIERTA DE ESTE ALTAVOZ. NO HAY PARTES REPARABLES POR EL USUARIO ADENTRO. CONSULTE TODOS LOS SERVICIOS A UN TÉCNICO CALIFICADO.
Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor. Limpie solamente con un paño seco. Los usuarios deben exhibir una seguridad adicional y seguir todas las precauciones tal como se indican.

SÉCURITÉ

POUR RÉDUIRE LE RISQUE D'ÉLECTROCUTION, NE RETIREZ PAS LE COUVERCLE DE CETTE ENCEINTE. IL N'Y A AUCUNE PIÈCE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. RÉFÉREZ TOUTE RÉPARATION À UN TÉCHNICIEN QUALIFIÉ.
Pour éviter un incendie ou un choc électrique, n'exposez pas cet équipement à la pluie ou à l'humidité. Ne stockez pas ou n'utilisez pas ce produit à proximité de liquides, de sources de chaleur telles que des radiateurs, des registres de chaleur. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de plus de sécurité et suivre toutes les précautions telles qu'elles sont indiquées.

PBX-1520 GUIDE / GUÍA / GUIDE

FUNCTIONS

1. POWER: 110-220VAC power input.
2. AUX IN: Input to connect external audio devices.
3. USB & TF: USB port and TF card slot inputs.
4. Display: LED screen displays current mode and volume/frequency/time/track.
5. MODE: Press to toggle to BT, FM, USB/TF, AUX. Press and hold to change lights.
6. PREV: Press to select previous music track or radio station.
7. PLAY: Press to play or pause music playback. See TWS instruction for TWS button function.
8. NEXT: Press to select next music track or radio station.
9. MIC: Connect to microphone to record sound level of the microphone over the music sound level.
10. Press to record the microphone and to playback recording.
11. Battery indicator.
12. Microphone input.
13. Mic Mute: Turn MIC ON or OFF.
14. Power On/Off: Turn UPS switch.
15. Speaker volume control.
16. Treble sound control.
17. Bass sound control.
18. Microphone echo control.
19. Microphone delay control.
20. Microphone volume control.

FUNCIONES

1. ALIMENTACIÓN: Entrada de alimentación 110-220VAC.
2. AUX IN: Entrada para conectar dispositivos de audio externos.
3. USB y TF: Puerto USB y entradas para ranura para tarjeta TF.
4. Pantalla: La pantalla LED muestra el modo actual y el indicador de batería recargable.
5. MODE: Presione para alternar entre BT, FM, USB/TF, AUX. Mantenga presionado para cambiar las luces.
6. ANTERIOR: Presione para seleccionar la pista de música o estación de radio anterior.
7. REPRODUCIR: presione para reproducir o pausar la reproducción de música. Consulte la instrucción de TWS para conocer la función de botón TWS.
8. SIGUIENTE: presione para seleccionar la siguiente pista de música o estación de radio.
9. Presione para priorizar el nivel de sonido del micrófono sobre el nivel de sonido de la música.
10. Presione para grabar el micrófono y reproducir la grabación.
11. Indicador de batería.
12. Entrada de micrófono.
13. Cambiar para encender o apagar las luces.
14. Interruptor de encendido y apagado.
15. Control de volumen del altavoz.
16. Control de sonido agudo.
17. Control de sonido bajo.
18. Control de eco del micrófono.
19. Control de retardo del micrófono.
20. Control de volumen del micrófono.

FUNCTIONS

1. PUISSANCE : entrée d'alimentation 110-220VAC.
2. AUX IN : Entrée pour connecter des appareils audio externes.
3. USB et TF : ports USB et entrées pour emplacement pour carte TF.
4. Affichage : l'écran LED affiche le mode actuel et l'indicateur de batterie rechargeable.
5. MODE : Appuyez pour basculer entre BT, FM, USB/TF, AUX. Appuyez et maintenez pour changer de lumière.
6. PREV : Appuyez pour sélectionner la piste musicale ou la station de radio précédente.
7. PLAY : Appuyez pour lire ou mettre en pause la lecture de la musique. Voir les instructions TWS pour la fonction du bouton TWS.
8. SUIVANT : Appuyez pour sélectionner la piste musicale ou la station de radio suivante.
9. Appuyez pour donner la priorité au niveau sonore du microphone par rapport au niveau sonore de la musique.
10. Appuyez pour enregistrer le microphone et lire l'enregistrement.
11. Indicateur de batterie.
12. Entrée micro.
13. Interrupteur pour allumer ou éteindre les lumières.
14. Interrupteur marche/arrêt.
15. Contrôle du volume du haut-parleur.
16. Contrôle des aigus.
17. Contrôle du son des basses.
18. Contrôle de l'écho du microphone.
19. Contrôle du retard du microphone.
20. Contrôle du volume du microphone.

PBX-1520 OPERATION / OPERACIÓN / OPÉRATION

POWER SOURCE

1. Charge the unit at least four hours prior to first use and then recharge it as needed in the future.
2. Turn the Power Knob to turn on power on/off.

CHARGE THE BATTERY

Plug the AC power cable into the charging port. When charging, the charging indicator light shows red and turns off when fully charged.
1. Securely connect the AC power cable to the charging port of the speaker.
2. After the battery is fully charged, disconnect the AC power cable from the charging port of the speaker.

FM FUNCTION

1. Press the MODE button to toggle to FM mode.
2. Press the PLAY/PAUSE button on the control panel to automatically the FM radio.
3. Then press PREVIOUS or NEXT to select and listen to saved radio stations.

BLUETOOTH

1. Press the MODE button to toggle to Bluetooth (BT) mode.
2. Open the Bluetooth setting on your phone, tablet or any other Bluetooth-enabled audio device and select "QFX PBX-1520".
3. The unit and device will then connected via Bluetooth.

PBX-1520 TRUE WIRELESS STEREO (TWS)

True Wireless Stereo (TWS) allows for two speakers of the same model to connect wirelessly in stereo. You will need two QFX PBX-1520 speakers in order for TWS operation to function. **To set up TWS**:
1. Turn on both of **QFX PBX-1520** speakers, toggle the MODE button to BLUETOOTH mode on both speakers.
2. To set up TWS operation, press the TWS button on only one speaker for 3 seconds. Then both speakers will connect together.
3. Next, connect your Bluetooth-enabled phone to the speaker. Go to your phone Bluetooth settings, search and connect to Bluetooth name "QFX PBX-1520".
4. Once the connection has been established, you can play music from your phone and enjoy True Wireless Stereo audio playing through your two QFX PBX-1520 speakers.

5. To exit TWS mode, long press the PLAY ►II TWS button for 3 seconds to exit TWS.

FUENTE DE ALIMENTACIÓN

1. Cargue la unidad al menos cuatro horas antes del primer uso y luego recárgala según sea necesario en el futuro.
2. Mantenga presionado el botón de ENCENDIDO para encender/apagar

CARGA LA BATERÍA

Conecte el cable de alimentación de CA al puerto de carga; durante la carga, la luz indicadora de carga se ilumina en rojo y se apaga cuando está completamente cargada.
1. Conecte de forma segura el cable de alimentación de CA al puerto de carga del altavoz.
2. Después de que la batería esté completamente cargada, desconecte el cable de alimentación CA del puerto de carga del altavoz.

FUNCIÓN FM

1. Presione el botón MODO para cambiar al modo FM.
2. Presione y mantenga presionado el botón REPRODUCIR/PAUSA en el panel de control para escuchar automáticamente la radio FM.
3. Luego presione ANTERIOR o SIGUIENTE para seleccionar y escuchar las estaciones de radio guardadas.

BLUETOOTH

1. Presione el botón MODE para cambiar al modo Bluetooth (BT).
2. Abra la configuración de Bluetooth en su teléfono, tableta o cualquier otro dispositivo de audio habilitado para Bluetooth y seleccione "QFX PBX-1520"
3. La unidad y el dispositivo se conectarán a través de Bluetooth.

PBX-1520 OPERATION / OPERACIÓN / OPÉRATION

PBX-1520 ESTÉREO INALÁMBRICO VERDADERO (TWS)

True Wireless Stereo (TWS) permite que dos altavoces del mismo modelo se conecten de forma inalámbrica en estéreo. Necesitará dos altavoces **QFX PBX-1520** para que funcione la operación TWS. **Para configurar TWS**:

True Wireless Stereo (TWS) permite conectar dos altavoces del mismo modelo de forma inalámbrica en estéreo. Necesitará dos altavoces **QFX PBX-1520** para que funcione el funcionamiento TWS. Para configurar TWS:
1. Encienda ambos altavoces **QFX PBX-1520**, cambie el botón MODE al modo BLUETOOTH en ambos altavoces.
2. Para configurar el funcionamiento de TWS, presione el botón TWS en un solo altavoz durante 3 segundos. Entonces ambos altavoces se conectarán entre sí.
3. A continuación, conecte su teléfono inteligente habilitado para Bluetooth. Vaya a la configuración de Bluetooth de su teléfono, busque y conecte con el nombre de Bluetooth "QFX PBX-1520".
4. Una vez que se haya establecido la conexión, podrá reproducir música desde su teléfono y disfrutar del audio estéreo inalámbrico verdadero a través de sus dos parlantes **QFX PBX-1520**.
5. Para salir del modo TWS, mantenga presionado el botón PLAY ►II TWS durante 3 segundos para salir de TWS.

SOURCE D'ÉNERGIE

1. Chargez l'appareil au moins quatre heures avant la première utilisation, puis rechargez-le si nécessaire à l'avenir.
2. Appuyez et maintenez enfoncé le bouton POWER pour allumer/éteindre.

CHARGER LA BATTERIE

Branchez le câble d'alimentation CA dans le port de charge. Lors du chargement, le voyant de charge s'allume en rouge et s'éteint lorsqu'il est complètement chargé.
1. Connectez solidairement le câble d'alimentation CA au port de charge du haut-parleur.
2. Une fois la batterie complètement chargée, débranchez le câble d'alimentation secteur du porte-charge de l'enceinte.

FONCTION FM

1. Appuyez sur le bouton MODE pour passer en mode FM.
2. Appuyez et maintenez enfoncé le bouton PLAY/PAUSE du panneau de commande pour activer automatiquement la radio FM.
3. Appuyez ensuite sur PRÉCÉDENT ou NEXT pour sélectionner et écouter les stations de radio enregistrées.

BLUETOOTH

1. Appuyez sur le bouton MODE pour passer en mode Bluetooth (BT).
2. Ouvrez le paramètre Bluetooth sur votre téléphone, tablette ou tout autre appareil audio compatible Bluetooth et sélectionnez "QFX PBX-1520"
3. L'appareil et l'appareil seront ensuite connectés via Bluetooth.

PBX-1520 OPERATION / OPERACIÓN / OPÉRATION

PBX-1520 ESTÉREO INALÁMBRICO VERDADERO (TWS)

True Wireless Stereo (TWS) permite que dos altavoces del mismo modelo se conecten de forma inalámbrica en estéreo. Necesitará dos altavoces **QFX PBX-1520** para que funcione la operación TWS. **Para configurar TWS**:

True Wireless Stereo (TWS) permite conectar dos altavoces del mismo modelo de forma inalámbrica en estéreo. Necesitará dos altavoces **QFX PBX-1520** para que funcione el funcionamiento TWS. Para configurar TWS:
1. Encienda ambos altavoces **QFX PBX-1520**, cambie el botón MODE al modo BLUETOOTH en ambos altavoces.
2. Para configurar el funcionamiento de TWS, presione el botón TWS en un solo altavoz durante 3 segundos. Entonces ambos altavoces se conectarán entre sí.
3. A continuación, conecte su teléfono inteligente habilitado para Bluetooth. Vaya a la configuración de Bluetooth de su teléfono, busque y conecte con el nombre de Bluetooth "QFX PBX-1520".
4. Una vez que se haya establecido la conexión, podrá reproducir música desde su teléfono y disfrutar del audio estéreo inalámbrico verdadero a través de sus dos parlantes **QFX PBX-1520**.
5. Para salir del modo TWS, mantenga presionado el botón PLAY ►II TWS durante 3 segundos para salir de TWS.

SOURCE D'ÉNERGIE

1. Chargez l'appareil au moins quatre heures avant la première utilisation, puis rechargez-le si nécessaire à l'avenir.
2. Appuyez et maintenez enfoncé le bouton POWER pour allumer/éteindre.

CHARGER LA BATTERIE

Branchez le câble d'alimentation CA dans le port de charge. Lors du chargement, le voyant de charge s'allume en rouge et s'éteint lorsqu'il est complètement chargé.
1. Connectez solidairement le câble d'alimentation CA au port de charge du haut-parleur.
2. Une fois la batterie complètement chargée, débranchez le câble d'alimentation secteur du porte-charge de l'enceinte.

FONCTION FM

1. Appuyez sur le bouton MODE pour passer en mode FM.
2. Appuyez et maintenez enfoncé le bouton PLAY/PAUSE du panneau de commande pour activer automatiquement la radio FM.
3. Appuyez ensuite sur PRÉCÉDENT ou NEXT pour sélectionner et écouter les stations de radio enregistrées.

BLUETOOTH

1. Appuyez sur le bouton MODE pour passer en mode Bluetooth (BT).
2. Ouvrez le paramètre Bluetooth sur votre téléphone, tablette ou tout autre appareil audio compatible Bluetooth et sélectionnez "QFX PBX-1520"
3. L'appareil et l'appareil seront ensuite connectés via Bluetooth.

QFX

LIMITED PRODUCT WARRANTY POLICY

1 YEAR WARRANTY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully, and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (hereinafter called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, noncommercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product for any component thereof during the applicable Warranty Period, QFX will, at its sole discretion, repair or replace the Product or component thereof, free of charge to Customer for Parts and/or Labor (as applicable) during the applicable Coverage Period; or (b) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, excluding applicable shipping charges (collectively, the "Warranty"). Repaired or replaced Products or components will be delivered to the Customer's residence remedy and QFX's sole liability for breach of the limited warranty contained herein.

This warranty covers only normal, bona fide, noncommercial use by the Customer. QFX is not responsible for voluntarily replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in water, improper installation, improper maintenance, improper packaging, improper shipping, improper handling, improper storage. This warranty excludes any Product (or, as applicable, any component thereof) that has been subject to a Defective resulting from (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) caused by improper packaging, improper shipping, improper handling, improper storage, improper installation, improper maintenance, improper use, improper operation, improper care, or improper connections; (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, noncommercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is not adequate for medical or lifesaving applications. QFX disclaims any liability for any of the foregoing cases to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR THE WARRANTIES EXPRESSLY MADE HEREIN, TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE SOLD "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS, (iv) OF TITLE, (v) OF ACCURACY OF TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NO EMPLOYEE, AGENT, OR REPRESENTATIVE OF ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE TYPE OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL QFX'S LIABILITY EXCEED THE PURCHASE PRICE OF THE PRODUCT WHICH CAUSES THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warranty: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PRIEPAID to the address below in the original packaging or reasonable substitute to prevent damage and indicate (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that evidences the purchase of the Product; (2) your name, address, and a daytime phone number; (3) a description of the Defect; (4) the serial number; (5) Customer's full name, phone number, and return address; (6) all of the accessories that came with the Product package must be sent along with the main Product; (6) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-1148 (1582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or pad for the product being returned, please refer to the table below. Please find the product you wish to return, by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth speakers	$5.00	1 Year	1 Year
Personal Stereos	$10.00	1 Year	1 Year
Portable Radio Cassette	$15.00	1 Year	1 Year
Large Portable Radio Cassette	$20.00	1 Year	1 Year
Mobile Audio	$10.00	1 Year	1 Year
Pro Audio SBX Systems	$75.00	1 Year	1 Year
Pro Audio PBX Systems	$75.00	1 Year	1 Year
Televisions	$25.00	1 Year	1 Year
Telephones	$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE LIMITED WARRANTY PERIOD. IF THESE LAWS APPLY, THEN ALL EXPRESSED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specified legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©

1-800-864-2582
Mon-Fri 9AM - 5PM (PST)

support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)

www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your PBX-1520 Journey!
Tag us @QFXUSA to share your stories.

FOLLOW US @QFXUSA